

Mounting Instruction : Type I Switch & Socket




WARNING

Before installation, please read these installation instructions carefully.

1. Please install the switches and sockets only after all wall decorations have been completed to ensure that no dust enters the products, which could cause poor contact.
2. To prevent the risk of electrocution, turn off the mains electricity supply before commencing work.
3. The device must be installed and connected by skilled electricians. Otherwise it may cause short circuit or even fire.


STEP
1

Clean the walls and ensure that the surfaces are even.




STEP
2

Distribute the power cables according to the required functions.




STEP
3

Remove the module from the packaging. Inspect the product for integrity, and separate the panel from the module.




STEP
4

Remove the module from the packaging. Inspect the product for integrity, and separate the panel from the module.




STEP
5

Install the outer frame component onto the mounting junction box using the provided screws. Please note that the torque must not exceed 6 kg·f, as exceeding this limit may cause deformation of the steel frame and affect its functionality.




STEP
6

Connect the power cable to the module. Please refer to the wiring diagram of each product for the correct wiring method.




STEP
7

Connect the power cable to the module. Please refer to the wiring diagram of each product for the correct wiring method.




STEP
8

Push the fully wired module into the outer frame assembly and check whether it is properly seated.




STEP
9

Assemble the module panels onto their corresponding modules.




STEP
10

Installation complete.




Wiring Diagram : Switch Type I


1 Gang 1 Way Switch




2 Gang 1 Way Switch




3 Gang 1 Way Switch




4 Gang 1 Way Switch




1 Gang 2 Way Switch




2 Gang 2 Way Switch




3 Gang 2 Way Switch



4 Gang 2 Way Switch



1 Gang Intermediate Switch



2 Gang Intermediate Switch

